

- Minimum to Download
 - » Mingw version of ATP
 - » ATPDraw -- latest version or latest patch
 - Presently version 6.2
 - PlotXY
- Installation complete set is a little tricky
- Option: ATP Easy Installer
 - » Download from secure sites in Japan

- Installation is fairly easy
- Default installation path “Program Files”
- The space in the file name can create problems running ATP from ATPDraw
 - » Install it somewhere else. I normally install in “C:\tools\prog\ATPDraw”
- Install program creates shortcut in the start menu, but not very cleanly

- Still need a copy of ATP
- Licensed users can get other versions
- Follow installation directions for yours
- ATPDraw calls ATP
- Passes full path to data file when it calls ATP

- Second line adds executable to your search path (not needed if set this at boot time)
- The next line calls ATP itself
 - » `tpbig both %1 s -R`
 - “both” tells program to write error messages to screen and to file (useful for debugging)
 - Could also set “disk” to only do disk file or leave blank for no message
 - First “%1” is input data file from ATPDraw

Sample Batch File (cont.)

- The “s” is to create appropriate output file.
- “-R” tells ATP overwrite existing output file if one exists
- This bat file will let you run ATP, and all of the support program (line constants etc)


Editing “startup”

- ATP reads a file called “startup”
 - » Resides in same directory as tpbig
 - » Sets variables for the program
- A few suggested changes from default
 - » Change PL4 file format to work with PlotXY
 - NOBLAN set to 0 {ignore blank lines}
 - NEWPL4 set to 2 {won't work with Analyzer}

Setting Up ATPDraw


- Open up ATPDraw
- Select: “Tools” pull down menu
- Select: “Options...”
- Choose “Preferences” tab
 - » You select a text editor, or use Notepad (default)
 - » “ATP” is where you set path to your batch file
- Armafit: which we won't cover in this course

ATPDraw “Preferences”



- The “Files&Folders” tab settings are ok
- However, you do want changes in the View/ATP tab

- » Select “Edit settings” tab
- » You may want to change some of the default settings. However, you can change any of these for a specific data file




Intro to ATP


9

Fall 2018

- Default time step (deltaT) is very small
- Default run time short
- Xopt and Copt ok
- Select “Power Frequency”
 - » Reset to 60 Hz from 50Hz
 - » Can mess up some sources



- Probably don’t need the selected “Printout” options for most cases
- Slow down the program somewhat
- Plot frequency should be low and odd.



Intro to ATP

11

Fall 2018

- Switch/UM settings ok for most cases (are for statistical studies only)
- Load flow controls how the load flow initialization is run
- Variables: Use can define parameters here and pass them different components
 - » Or control them with Pocket Calculator option
 - » See help file for more info

Intro to ATP

10

Fall 2018

Intro to ATP

12

Fall 2018

UI

ECE 525
Lecture 13

Saving New Settings

- The “Save” or “Apply” buttons aren’t sufficient to permanently save change
- Also choose: Tools --> Save Options
- These are all saved into a file called ATPDraw.ini
 - » Typically saved in user’s settings
 - » Could put copy in the directory with ATPDraw.exe

Intro to ATP

13

Fall 2018

UI

ECE 525
Lecture 13

Other Settings

- To set other plotting programs or other post processing options you need to open a file
 - » Either select the “File|Open” sequence of click on the icon
 - » Initial default is the Examples directory, after that it is the last directory worked in.
 - » For now, choose example “Exa_1.adp” (*.adp represents the drawing files).

Intro to ATP

14


Fall 2018

UI

ECE 525
Lecture 13

Example 1

- Try to run example case to make sure program installed and set up correctly



Intro to ATP

15


Fall 2018

UI

ECE 525
Lecture 13

ATP Menu

- A new pulldown menu is now available at the top of the window, called “ATP”




Intro to ATP

UI ATP Menu

ECE 525
Lecture 13

- Settings is changes deltaT etc. for a given case
- “Make File As” generates ATP data file from drawing
- Run ATP calls your bat file
- Each “Edit” calls text editor
- Make Names, makes node names for drawing



Intro to ATP


17

Fall 2018

UI Edit Commands

ECE 525
Lecture 13

- Allows you to set additional commands
- Run other ATP versions
 - » On Current ATP drawing
 - » On Selected File
- Run plot programs
 - » On Current PL4
- Use “Update” to set



Intro to ATP

18

Fall 2018

UI Saving New Settings

ECE 525
Lecture 13

- The “Update” buttons isn’t sufficient to save for next time
- All choose: Tools --> Save Options

Intro to ATP

19

Fall 2018

UI Running an ATP File

ECE 525
Lecture 13

- Now we run the example case opened earlier
- Always a multi-step process
 - » 1) Make file to create ATP data file from drawing.
 - Must do this every time you change drawing
 - Default is to place this in “ATP” subdirectory under ATPDraw home directory (with extension *.ATP)
 - Can edit this file with “Edit ATP-File” option (not saved to drawing file)
 - » 2) Run your case
 - » 3) Call plotting program

Intro to ATP

20

Fall 2018

UI Running an ATP File

ECE 525
Lecture 13

- The drawing file saved separately (save often)
- Remember to save your changes often
- Default is to save this in the “Project” subdirectory under ATPDraw
- Note that if want to save elsewhere, need to select a new home for both ADP and ATP files
 - » PL4 and *.lis (or *.out depending on version) are written to same directory at *.ATP file
 - » Need to cleanup directories periodically

Intro to ATP


21

Fall 2018

UI Making You Own File

ECE 525
Lecture 13

- Open a new drawing (from File menu or from icon)
- Can get the component menu by right clicking mouse in the drawing screen
- Each item lets you select components to create
- More later....



Intro to ATP

22

Fall 2018

UI Associated Files

ECE 525
Lecture 13

- Input Datafile (text file)
 - » Extension options: *.dat or *.atp (ATPDraw)
 - » Avoid Long File Names
- Plot Datafile (formatted ASCII)
 - » Extension *.PL4
- Text Output File (plain text)
 - » Extension: *.LIS (or *.OUT)
 - » Error Messages in this file

Intro to ATP

23

Fall 2018

UI Associated Files (cont)

ECE 525
Lecture 13

- ATPDraw Schematic File
 - » Extension: *.acp (or *.adp for older versions)
- Supplement Include File
 - » Use modular programs
 - » Examples: Line constants output, subsystems
 - » Extension options: *.pch, *.pun, *.lib

Intro to ATP

24

Fall 2018

UI Creating a File: Text Based

ECE 525
Lecture 13

- Use fixed width fonts with your text editor
 - » If use MS-Word or Word-Pad make sure use Courier
- Plain text editor better option
 - » Best if it provides column number
- Older ATP versions do not perform type checking, use all upper case for variables
- Column alignment is very important
- The ATP rule book refers to individual lines as data cards

Intro to ATP

25

Fall 2018

Intro to ATP

27

Fall 2018

UI Sample File

ECE 525
Lecture 13

```
C Brian K. Johnson
C Simulation for Problem 3.11 in Greenwood
BEGIN NEW DATA CASE
C ..... Miscellaneous data .....
C DeltaT<---TMax<---XOpt<---EpsiIn<---TolMat<---TStart
5.0E-5 0.1
C --IOut<---IPlot<---IDoubl<---KSSOut<---MaxOut<---IPun<---MemSav<---ICat<---NEnerg<---IPrSup
500 1
C ..... Circuit data .....
C Bus1->Bus2->Bus3->Bus4-><---R<---L<---C
VS V1 0.149 4.73
BLANK ends circuit data
C ..... Switch data .....
C **** Close at 160 degrees, or 70 degrees past peak *****
C Bus-->Bus--><---Tclose<---Topen<---Ie 0 1
V1 0.02407 999.
BLANK ends switch data
C
```

Intro to ATP

26

Fall 2018

Intro to ATP

28

Fall 2018

UI Sample File (cont.)

ECE 525
Lecture 13

```
C ..... Source data .....
C Bus-->I<Amplitude<Frequency<---TO|Phi0<---0=Phi0 <---Tstart<---Tstop
14VS 28.16913E3 60. -90. 0. -1. 9999.
BLANK ends source data
C ..... Output Request Data .....
C Bus-->Bus-->Bus-->Bus-->Bus-->Bus-->Bus-->Bus-->Bus-->
V1 VS
BLANK ends output requests
BLANK ends plot request
BEGIN NEW DATA CASE
BLANK ends all cases
```

Intro to ATP

27

Fall 2018

UI Sections of the Datafile

ECE 525
Lecture 13

- An ATP datafile must at a minimum have the following sections
 - » Header/Miscellaneous Data Cards
 - » Circuit Data
 - » Switch Data
 - » Source Data
 - » Output request data
 - » Plot request data

Intro to ATP

28

Fall 2018

UI Sections of the Datafile

ECE 525
Lecture 13

- End of section marked with “BLANK” starting in column 1
 - » Rest of the card is comment
 - » An accidental blank line in data file is treated as end of section – fix in startup file discussed earlier
- Graphical interfaces such as ATPDraw insulate user from needing to work at this level
- Still useful to know what is going on at this level
 - » For Debugging
 - » If someone sends you an older file

Intro to ATP

29

Fall 2018

UI Comment Cards

ECE 525
Lecture 13

- Good practice to have comments in the file
- Comments start with a “C” in column 1 and a blank in column 2

```
C *****
C * This is a sample comment *
C *****
```
- ATP allows “in-line” comments. Place comment between “{ and }”
- Make sure that you don't block useful data fields

Intro to ATP

30

Fall 2018

UI Comment Cards (cont.)

ECE 525
Lecture 13

- User can also treat a block of code between keywords \$DISABLE and \$ENABLE

```
$DISABLE
all lines in between keywords are ignored
$ENABLE
```

Intro to ATP


31

Fall 2018

UI Making You Own File

ECE 525
Lecture 13

- **Set deltaT and Tmax!!!**
- **Open a new drawing (from File menu or from icon)**
- **Can get the component menu by right clicking mouse in the drawing screen**
- **Each item lets you select components to create**



Intro to ATP

32

Fall 2018

UI Linear Branches

ECE 525
Lecture 13

- These are the basic circuit elements
- Single phase and three phase options
- C:U(0) and L:I(0) are capacitor and inductor with voltage/current initial conditions
- Note ATPDraw uses U for voltage



Intro to ATP

33

Fall 2018

UI Operating on component

ECE 525
Lecture 13

- Once you select a component you can rotate it by single clicking the right mouse button on it.
 - » Use to structure your drawing more nicely
 - » This also selects polarity for branch outputs
- Double-click left button to open a window to edit values

Intro to ATP


34

Fall 2018

UI Resistor Dialog Box

ECE 525
Lecture 13

- Set value for resistance in Ohms
- Node names not set
- Can add comment
- \$Vintage, 1 sets high precision numbers
- Edit definitions: allows redefine model-advanced feature



Intro to ATP

35

Fall 2018

UI Resistor Dialog Box

ECE 525
Lecture 13

- Set branch output:
 - 0 - No
 - 1 - Current
 - 2 - Voltage
 - 3 - Current&Voltage
 - 4 - Power&Energy
- Comments
 - » For file
 - » For drawing

Intro to ATP


36

Fall 2018

UI

Inductor


- L is in mH unless you have set Xopt to a frequency
- Label creates a label on the drawing next to the component
- Help menus are pretty good
- Kp numerical oscillation damping constant
 - » Adds parallel resistor
 - » More on that later



UI

Capacitor


- Capacitance is in microFarads unless Copt set
- Note program sets a default value to prevent errors if you randomly connect nodes
- Ks numerical oscillation damping constant
 - » Adds series resistor
 - » More on that later



UI

RLC


- RLC lets you set R, L, and C or any combination
- Creates same data card as R, L, or C alone, but lets you do all fields
- Series RLC



UI

3 Phase RLC


- Can choose a series 3 phase RLC
- Options include Y connected
- and Delta connected



UI Capacitor with Initial Voltage Value

ECE 525
Lecture 13

- Still set value for C
- Also set positive and negative voltage relative to ground at T=0
- Will be useful for homework #1



Intro to ATP


41

Fall 2018

UI Inductor with Initial Current Value

ECE 525
Lecture 13

- Still set value for L
- Plus the current at T=0



Intro to ATP


42

Fall 2018

UI Switch Pop Up Menu

ECE 525
Lecture 13

- In most cases you will use a time controlled switch (single or three phase)
- Measuring Switches (always closed)
- TACS controlled switches




Intro to ATP


43

Fall 2018

UI Time Controlled Switch

ECE 525
Lecture 13

- Set T_close 
- Set T_open
 - » T_open must be larger than T_close
- Imar is absolute value of current it will interrupt
- Can select outputs



Intro to ATP


44

Fall 2018

UI Time Controlled Switch

ECE 525
Lecture 13

- Can also set a time sequenced for repeated open/close operations.
- Up to 16



Intro to ATP


45

Fall 2018

UI Three Phase Switch

ECE 525
Lecture 13

- Individual timing for each phase
- No reclose characteristic



Intro to ATP


46

Fall 2018

UI Measuring Switch

ECE 525
Lecture 13

- No fields to set, but you must select "Current" output



Intro to ATP



47

Fall 2018

UI Source Pop Up Menu

ECE 525
Lecture 13

- Allows you to create ordinary sources
- Machines and TACS controlled sources on other pop-up menus
- Most of these sources are referenced to ground



Intro to ATP


48

Fall 2018

UI

Type 11 Source

ECE 525
Lecture 13



Intro to ATP

49

Fall 2018

UI


Version 5.6+ AC source (1&3 phase)

ECE 525
Lecture 13

1 ph voltage
source



3 ph current
source



Intro to ATP


50

Fall 2018

UI

Single Phase AC Source (ATPDraw 5.5 or earlier)

ECE 525
Lecture 13



Intro to ATP


51

Fall 2018

UI

Three Phase AC Source (ATPDraw 5.5 or earlier)

ECE 525
Lecture 13



Intro to ATP


52

Fall 2018

UI AC or DC Floating Source

ECE 525
Lecture 13

- AC source implemented using the Ideal Transformer Component
- Frequency default is 50Hz unless you change default power frequency in settings menu
- Better to use a Norton equivalent to create ungrounded (as dc does)



Intro to ATP

53

Fall 2018

UI Creating a Circuit

ECE 525
Lecture 13

- Components are highlighted in red until you edit values
- Can connect components together by dragging left mouse button between nodes and then clicking on finishing node
- 1 Ph or 3 Ph on context



Intro to ATP


54

Fall 2018

UI Selecting Node Names

ECE 525
Lecture 13

- Double click left button to get node data window
- Type node name in SWT
 - » 6 characters max
 - » ALL CAPS or numbers or will have errors
- Can ground the node
 - » Name won't matter
 - » Ground symbol will appear



Intro to ATP

55

Fall 2018

UI Selecting Node Names

ECE 525
Lecture 13


- Can choose to Display name on the screen
- If you have a connection between nodes, all nodes will get a name you assigned when use "Sub-process > Make Node Names" or "Make ATP File"
 - » ATPDraw assigns names if you don't (XX0001, etc)

Intro to ATP


56

Fall 2018

- Can also copy your components
- Remembers output requests and values
- Need to enter new names



- Menu for voltage and current measurements
- “Probe Volt” is line to ground voltage
- “Probe Branch Volt” “puts in dummy branch as does “probe curr”
- Select 1 or 3 ph



- File itself is less readable:

```
BEGIN NEW DATA CASE
C -----
C Generated by ATPDRAW January, Wednesday 23, 2008
C A Bonneville Power Administration program
C by H. K. Høidalen at SEFAS/NTNU - NORWAY 1994-2006
C -----
C dT >< Tmax >< Xopt >< Copt >
5.E-5 .1
500 1 1 1 1 0 0 1 0
C 1 2 3 4 5 6 7 8
C 34567890123456789012345678901234567890123456789012345678901234567890
/BRANCH
C < n1 >< n2 >< ref1><ref2>< R >< L >< C >
C < n1 >< n2 ><ref1><ref2>< R >< A >< B >< Leng><><>0
VS RL .149
RL LV 4.73
```

```
/SWITCH
C < n 1>< n 2>< TcIose ><Top/Tde >< Ie ><VF/CIOP >< type >
LV .02407 1.E3 1
/SOURCE
C < n 1><>< Amp1. >< Freq. ><Phase/T0>< A1 >< T1 >< TSTART >< TSTOP >
14VS 0 28169. 60. -90. -1. 1.E3
/OUTPUT
VS
BLANK BRANCH
BLANK SWITCH
BLANK SOURCE
BLANK OUTPUT
BLANK PLOT
BEGIN NEW DATA CASE
BLANK
```


UI

When handing in homework assignments

ECE 525
Lecture 13

- Include any hand calculations you did to set up the problem
- Include circuit diagram
- Include text from the *.atp file
- Include simulation plots
 - » Zoom in on key results
 - » Capture key numbers
 - » Interpretation of the results matters!
- See examples in upcoming lectures

Intro to ATP

61


Fall 2018

UI

Lumped Parameter Lines: ATP

ECE 525
Lecture 13

- All three model coupled branches
- Can do varying number of phases (up to 6)
- Can do several hundred phases when create by hand



Intro to ATP

62


Fall 2018

UI

Coupled PI: ATP

ECE 525
Lecture 13

- Good for shorted lines or cables
- Often need 10 segments for accurate line model
- Enter the matrix data in the menu
- Notice the scroll bar



Intro to ATP

63

Fall 2018

UI

Coupled RL: ATP

ECE 525
Lecture 13

- Enter using coupled-pi
- Don't enter capacitance values
- Use for network equivalent



Intro to ATP


64

Fall 2018

UI Coupled RL-Symmetrical Component Equivalent

ECE 525
Lecture 13

- Variation on coupled-RL
- Now do a symmetrical components equivalent
- Positive and zero sequence



Intro to ATP


65

Fall 2018

UI Transposed Line: ATP

ECE 525
Lecture 13

- Can enter the valid fields:
 - » Modal resistance per length
 - » Modal L'C' or
 - » Modal Zc and v or
 - » Modal Zc tau



Intro to ATP


67

Fall 2018

UI Distributed Parameter Lines: ATP

ECE 525
Lecture 13

- Transposed or untransposed options
- Transposed options listed here
- Fewer options for the untransposed



Intro to ATP


66

Fall 2018

UI Untransposed Line: ATP

ECE 525
Lecture 13

- Can enter the valid fields:
 - » Resistance/length
 - » A, B for modes
 - » Length
 - » ILINE controls A,B
 - » Transformation matrix



Intro to ATP

68

Fall 2018

UI

Finding Line Data

ECE 525
Lecture 13

- The line constants routine starts out from physical data concerning line
 - » Tower configuration
 - » Conductor sizes
 - » Resistivity of earth
 - » Bundling
 - » Transposition
 - » Set frequency or range for frequency sweep

Intro to ATP

69


Fall 2018

UI

ATPDraw Line Constants Program

ECE 525
Lecture 13

- ATPDraw will let user call the line constants program
- User determines number of phases
- Can do constant frequency parameter and frequency dependent
- Connect line model into circuit schematic



Intro to ATP

70


Fall 2018

UI

Overhead Line

ECE 525
Lecture 13

- If skin effect is checked LCC performs computation
 - » Otherwise user provides data
- Segmented ground
- Real transformation better for transients
- Model type
 - » Bergeron and pi for now
- Save as to save line model data
- Can import *.alc file with line data



Intro to ATP

71


Fall 2018

UI

Conductor Data

ECE 525
Lecture 13

- Add row to add additional conductors
 - » Phase 0 ground wires
 - » If don't auto bundle will need 2 or 3 per phase
- Run ATP to create data file entry at module
 - » Will run automatically if try to run a case
- View lets you see physical layout
- Verify analyzes frequency response of the model




Intro to ATP

72

Fall 2018


Coupled Pi Output

- Can request printed output to text file
 - » Can use this to collect matrix data to analysis in other programs
 - » Ze is equivalent 3x3
 - » Zs is symmetrical components
 - » Z calculated at initial frequency



Example Case


- If number of phases is multiple of 3 ATPDraw assumes double or triple circuit line




Example Case

#	Rlo (inch)	Rln (inch)	Rrcs (ohm/mile DC)	Horiz (feet)	Vmax (feet)	Vmin (feet)	Separ (inch)	Alpha (deg)	NB
1	0	0.608	0.0832	-10	55	55	15	-90	3
2	0	0.608	0.0839	0	72.32	72.32	15	-90	3
3	0	0.608	0.0839	10	55	55	15	-90	3

Example Case: View





Intro to ATP

78

Intro to ATP

Fall 2018

UI

What is Needed in Transformer Models?

- Amount of detail depends on frequency of desired response
- Power flow stability often just model leakage, perhaps winding resistance
 - » Tap changing
 - » Perhaps wye-delta phase shift

- Fault studies require more information
 - » Connection info
 - wye
 - delta
 - zig-zag
 - autotransformer
 - etc.
 - » Grounding
 - » Possible impact of tertiary

Intro to ATP

79

Fall 2018

UI

Low Frequency Transients

- Similar modeling info to fault programs
 - » Connection information more important
- Magnetizing branch
 - » Saturation
- Core loss term
- Not using per unit
 - » Need to include turns ratio
 - » Divide leakage L, winding R between windings

Intro to ATP

80

Fall 2018

UI Single Phase Equivalent Circuit

ECE 525
Lecture 13

- Winding resistance
- Leakage inductance
- Core loss--total losses
- Non-linear inductor model for magnetizing branch

Intro to ATP

81

Fall 2018

UI Ideal transformer component

ECE 525
Lecture 13

- Combines ideal transformer with ideal source
 - » Simply enter transformation ratio
 - » Can be used to implement floating source too
 - » Uses frequency from basic ATPDraw settings
 - Need to make sure this matches system frequency
 - Setting “Branch = 0” forces ATP to use this frequency
 - “Branch = 1” can avoid this ($V_m=1E-20$)

Intro to ATP

83

Fall 2018

UI ATP Options

ECE 525
Lecture 13

- Ideal transformer component
- Saturable transformer component
- BCTran -- preprocessor that converts description of transformer to coupled RL
- Can also create manually using coupled RL branches

Intro to ATP


82

Fall 2018

UI Accessing Transformer Models

ECE 525
Lecture 13

- Note that three phase and single phase options




Intro to ATP

84

Fall 2018

Dialog box



Text Entry

```
C .....Source data .....
C Bus--><I<AmpLitude<Frequency<--T0|Phi0<--0=Phi0 <---Tstart<---Tstop
14NodeJ
C NodeL><-|---n---><NodeK<NodeM<NodeX
18
```

- The 18 card need to follow the 14
- Node X can be used for current measurement

Adding R, L Terms


- The balance of the regular transformer model can be created by:
 - » Adding external R, L for series terms
 - » Shunt resistor for core loss term
 - » Saturable inductor component for L_m
- Create winding connections externally
- Can also add capacitance

Limitations


- Limited to two winding transformers
- *It is very easy to create numerical problems in the simulation with the ideal transformer*

- Model has built-in circuit elements
 - » Winding resistance
 - » Leakage inductance (can't enter 0)
 - » Core loss resistance
 - » Magnetizing branch
 - not entered as an L in mH
 - » Can set all except leakage to 0 to simplify
 - » Enter winding to winding ratios


- If RMS = 0, this is current versus flux
- If RMS = 1, this is RMS current versus RMS voltage at frequency of first source in the system
- The 0,0 point is assumed by the program
- Up to 10 points can be entered
 - » Better to limit to 3-5



- I_o , F_o are steady-state point on saturation characteristic for initial Lm
- RMS = 0 or 1: determines how the saturation characteristic is entered.
- Output is information about magnetization branch




- If RMS = 0, this is current versus flux
- If RMS = 1, this is RMS current versus RMS voltage at frequency of first source in the system
- The 0,0 point is assumed by the program
- Up to 10 points can be entered
 - » Better to limit to 3-5 for better numerical behavior
 - » Does not include hysteresis



UI

Three Phase Model


- Icon changes with the connection type. Here is three winding with all WYE
- Here is 2 winding with delta-wye
- Note that there is a point to connect to measure magnetizing branch voltage
- Three leg core option



UI

Three Phase Model

- Enter data for each winding
- Select Y, D, or Zig-zag
- Three leg option here, but better to use specific case from pull-down menu.




UI

Three Phase Model- Three Leg Core

- Option to model homopolar reluctance
 - » Saturable-Three Leg
- Much additional information needed.
- See help menu.

DATA	VALUE
ltd	1531
ltdl	35213
ltdh	115325
ltdh	900
ltdh	1183
ltdh	8825
ltdh	70
RMS	0




UI

BCTRAN Interface


- Produces coupled RL model
- Based on SC and OC test data
 - » Linear Lm internally
 - » Need to add external nonlinear

Options
 3-legged stacked core
 4-legged stacked core
 5-legged stacked core



UI Additional BC Tran Data

ECE 525
Lecture 13



Intro to ATP

97

Fall 2018

UI Nonlinear Devices

ECE 525
Lecture 13

- Models for resistors and inductors
 - » Differ model implementation
- The Type 98 and Type 93 inductors do not include hysteresis
 - » Same user data as saturation in saturable xfmr
 - » Set with initial conditions

R(0) Type 99
R(0) Type 92
R(0) Type 97
R(0) Type 91
L(0) Type 98
L(0) Type 93
L(0) Type 96
L(0) Hevia 98->96
MOV Type 92
MOV Type 3-ph
R(TACS) Type 91
L(0) Type 98, int
L(0) Type 96, int
L(0) Type 93, int

Intro to ATP


98

Fall 2018

UI Type 96 reactor with hysteresis

ECE 525
Lecture 13

- Option to enter residual flux along with steady-state



Intro to ATP


99

Fall 2018

UI Example

ECE 525
Lecture 13

- Transformer with saturation



Intro to ATP

100

Fall 2018

U_I Results from increasing voltage

ECE 525
Lecture 13

